




# First Boot and Login

assemblé par **Calسيوم**

Your IP PBX contains ETIX24 Elastix 2.4 management interface for Asterix . **For its setting the first login, please use the information below.**



You have three choices for starting your IPPBX.

## 1 - Using the serial port

If the default settings do not suit you . In this case , use a serial terminal , as PuTTY KITTY to connect to the IP PBX . Please configure your terminal settings serial connection indicate above. Once started you have access to the terminal.

## 2 - SSH authentication parameter

login : **root**  
password : **calسيوم**

## 3 - Access the WEB configuration port :

**https://10.10.10.10**

### WEB authentication setting Owner

login : **admin**  
password : **calسيوم**

### WEB authentication setting Super Administrator

login : **super**  
password : **calسيوم**